Revolution Mills



Installation instructions for Laminate

Important information

- The flooring must be acclimated a minimum of 24 to 48 hours prior to installation in the room where the installation will take place.
- In larger rooms the flooring must be installed in smaller sections with expansion joints.
- The distance to walls and other permanent pieces of construction elements (such as pillars and kitchen islands) should be approximately 1/16*.
- per meter of the lenght and width of the floor (width 10 m = 19/32" expansion gap).
- Never install very heavy pieces of furniture such as kitchen islands/cabinets on top of the flooring.
- The indoor climate should have a temperature between 59-73.4°F and relative air humidity between 30-60%.
- Always follow the floor manufacturers requirements and specifications regarding subfloor preparation.

General installation instructions



First row, first plank

Start in a left corner with the tongue side against the wall and work to the right.

Press down a wedge to the left to create a joint of at least 5/16"-13/32".



First row, second plank

Place the plank gently and tight to the short end of the first one.



Second row, first plank. Start with the rest of the cut plank from the first row.

start with the rest of the cut plank from the first re



Staggered joint distance i.e. minimum distance between short ends of plank in parallel rows shall not be less than the given length.



Fold the plank down in a single movement. Make sure the plank are tight against each other. *Note!* You should here a CLICK sound.



Second row, second plank.

Place the plank gently and tight o the short end of the previous plank and fold it down in a single action movement. Make sure the planks are tight against each other booth during and after this step.





Afterwards press slightly along the short end just installed.



After 2-3 rows.

Adjust the distance to the front wall by placing wedges. The joint should be at least 5/16"-13/32".





The first and last row may need to be adjusted at an uneven wall. Copy the wall line to the first or last plank row with the shown tool, disasamble planks, adjust and reinstall.


Installation around radiator/heating pipes





Drill holes two times larger than the diameter of the pipes. Remove a piece of the panel with a utility knife. Put the panel on one side of the pipes and the removed piece on the other side.

When angling is not possible



Remove the vertical locking element/ hook of the plank with a chisel, put applicable glue on the locking element and push the plank horizontally together. Place wedges between last glued plank and the wall.



2023-291-EN

Copyright © 2023 Välinge Innovation AB

5G Dry[®] is a trademark for a patented technology – invented, registered and owned by Välinge Innovation AB. Use of the mark or technology is under license.



Installation instructions for Laminate

Dismantling panels

2 alternatives

Dismantling with pin



Put the dismantling pin into the space between the tongue and groove on the short end of the plank.



The plank is now loose and you can easily lift the plank up.

Dismantling by sliding



Separate the whole row by carefully lifting up and release the whole row. Fold up the row and release the whole long side.



Disassemble the panels by sliding the short ends horizontally. *Never fold up a panel, as this damages the profile.*

